Basic model Single-axis robots Slider type

# Ordering method

ABAS08

Model

10: 10 mm

R: Right bending L: Left bending

BK: Standard/With brake BL: Battery-less absolute With no brake BKBL: Battery-less absolute 50 to 1100

(50mm pitch)

R3: 3 m R5: 5 m R10: 10 m R: From rear of motor

**EP-01** 

EP: EtherNet/IP
PT: PROFINET
ES: EtherCAT R: With EP-RU

N: None NS: NPN CC: CC-Link

Note 1. The robot cable is flexible and resists bending.

Note 2. When the actuator is used vertically and the stroke of lead 5 or 20 is 450 mm or more or the stroke of lead 10 is 150 mm or more, the regenerative unit is needed. When the actuator is used horizontally and the stroke of lead 20 is 250 to 750 mm, the regenerative unit is needed. Note 3. When the motor specification is the standard (S, BK), whether to use the battery needs to be selected.

#### ■ Specifications AC servo motor output 200 W Repeatability Note 1 +/-0.01 mm Shifting position ball screw \$\phi\$ 16 **Deceleration mechanism** (C7 class) Stroke 50 mm to 1100 mm (50 mm pitch) 1200 600 300 Maximum speed Note 2 mm/sec mm/sec mm/sec Ball screw lead 20 mm 10 mm 5 mm Horizontal 40 kg 80 kg 100 kg Maximum payload Vertical 8 kg 20 kg 30 kg Rated thrust 174 N 341 N 683 N Maximum dimensions of cross section W 82 mm × H 78 mm of main unit Straight ST + 353 mm Overall length Bending ST + 264.5 mm Absolute encoder Position detector Battery-less absolute encoder Resolution 23 bits

Note 1. Positioning repeatability in one direction

Using ambient temperature and humidity

Note 2. When a moving distance is short and depending on an operation condition, it may not reach the maximum speed.


If the effective stroke exceeds 650 mm, the ball screw may resonate. (Critical speed)
At this time, make the adjustment to decrease the speed while referring to the


0 to 40 °C, 35 to 80 %RH (non-condensing)

maximum speed shown in the table.

Note. See P.109 for acceleration/deceleration.

### Allowable overhang







### ABAS08-20

Horizontal installation			llation	(Unit: mm)	Wall in:	stallati	on (	Unit: mm)	Vertical installation (Unit: mm)					
		Α	В	С		Α	В	С		Α	С			
15	kg	356	131	146	15kg	146	131	356	3kg	634	634			
25	kg	278	73	86	25kg	86	73	278	6kg	321	321			
40	kg	517	54	76	40kg	76	54	517	8kg	240	240			

#### ABAS08-10

Horizontal installation			(Unit: mm)	Wall in:	stallati	on (	Unit: mm)	Vertical in	stallation	(Unit: mm)
	Α	В	С		Α	В	С		Α	С
30kg	465	83	120	30kg	120	83	465	5kg	551	551
50kg	341	44	65	50kg	65	44	341	10kg	270	270
80kg	228	22	34	80kg	34	22	228	20kg	129	129

### ABAS08-5


			llation	(Unit: mm)	Wall in	stallati	on (	Jnit: mm)	Vertical in	stallation	(Unit: mm)
Ī		Α	В	С		Α	В	С		Α	С
	30kg	1604	95	153	30kg	153	95	1604	10kg	312	312
	50kg	1035	52	83	50kg	83	52	1035	20kg	149	149
	80kg	719	27	44	80kg	44	27	719	30kg	95	95
	100kg	608	19	31	100kg	31	19	608		,	

Note. Distance from center of slider upper surface to carrier center-of-gravity at a guide service life of 10,000 km.

Note. Service life is calculated for 600mm stroke models.

#### Controller Controller Operation method EP-01 I/O point trace/Remote command


## Static loading moment



		(Unit: N·m
MY	MP	MR
221	309	343



▶ The cycle time simulation and service life calculation can be performed easily from our member site. For details, see P.12.




- Note 1. Stop positions are determined by the mechanical stoppers at both ends Note 2. When changing the return-to-origin direction, the parameter needs to be changed. (The standard is that the origin is located on the motor side.)
- Note 3. For the installation through hole, the length under head << 45 mm or more>> is recommended for the hex socket head bolts <M5 × 0.8>. In the installation tap hole, the length under head <<thickness of stand +15 mm or less>> is recommended for the hex socket head bolts <M6 × 1.0> used to install the main
- Note 4. Grease gun nozzle (recommended) (see P.143 for detail) Part number: KFU-M3861-00
- Note 5. Weight without brake. The weight with the brake is 0.4 kg heavier than the value
- in the weight column.

  Note 6. The robot cable is extracted from the front.
- Note 7. The robot cable is extracted from the rear.

  Note 8. The robot cable (with brake) is extracted from the front.
- Note 9. The robot cable (with brake) is extracted from the rear.
- Note 10. The fixed minimum bending radius of the robot cable is R30.

  When using the robot cable as a flexible cable, use it with a minimum bending radius of R50 or more.

- I ait	number. Ki O-Wi	0001-0																					
Effective stroke		50	100	150	200	250	300	350	400	450	500	550	600	650	700	750	800	850	900	950	1000	1050	1100
La		403	453	503	553	603	653	703	753	803	853	903	953	1003	1053	1103	1153	1203	1253	1303	1353	1403	1453
Lb		50	100	50	100	50	100	50	100	50	100	50	100	50	100	50	100	50	100	50	100	50	100
Lc		50	100	150	200	250	300	350	400	450	500	550	600	650	700	750	800	850	900	950	1000	1050	1100
Qa		6	6	8	8	10	10	12	12	14	14	16	16	18	18	20	20	22	22	24	24	26	26
	Qb	1	1	2	2	3	3	4	4	5	5	6	6	7	7	8	8	9	9	10	10	11	11
Weigh	it (kg) Note 5	4.5	4.9	5.3	5.6	6	6.3	6.6	7	7.3	7.6	8	8.3	8.7	9	9.3	9.6	10	10.2	10.6	10.9	11.3	11.7
	Lead 20							1200							1020	900	780	660	600	540	480	420	360
Maximum speed	Lead 10							600							510	450	390	330	300	270	240	210	180
(mm/sec)	Lead 5							300							255	225	195	165	150	135	120	105	90
(	Speed setting							-							85%	75%	65%	55%	50%	45%	40%	35%	30%



- Note 1. Stop positions are determined by the mechanical stoppers at both ends Note 2. When changing the return-to-origin direction, the parameter needs to be changed. (The standard is that the origin is located on the motor side.)
- Note 3. For the installation through hole, the length under head << 45 mm or more>> is recommended for the hex socket head bolts <M5 × 0.8>. In the installation tap hole, the length under head <<th>stocker head botts < 0.52 · m to installation tap hole, the length under head <<th>thickness of stand +15 mm or less> is recommended for the hex socket head bolts <M6 × 1.0> used to install the main
- Note 4. Grease gun nozzle (recommended) (see P.143 for detail)
- Note 5. Weight without brake. The weight with the brake is 0.4 kg heavier than the value in the weight column.
- Note 6. The robot cable is extracted from the front.
- Note 7. The robot cable is extracted from the rear.

  Note 8. The robot cable (with brake) is extracted from the front.
- Note 9. The robot cable (with brake) is extracted from the rear
- Note 10. The fixed minimum bending radius of the robot cable is R30.

  When using the robot cable as a flexible cable, use it with a minimum bending radius of R50 or more.

Part number: KFO-M3861-00																							
Effect	ive stroke	50	100	150	200	250	300	350	400	450	500	550	600	650	700	750	800	850	900	950	1000	1050	1100
	La	314.5	364.5	414.5	464.5	514.5	564.5	614.5	664.5	714.5	764.5	814.5	864.5	914.5	964.5	1014.5	1064.5	1114.5	1164.5	1214.5	1264.5	1314.5	1364.5
Lb		50	100	50	100	50	100	50	100	50	100	50	100	50	100	50	100	50	100	50	100	50	100
Lc		50	100	150	200	250	300	350	400	450	500	550	600	650	700	750	800	850	900	950	1000	1050	1100
Qa		6	6	8	8	10	10	12	12	14	14	16	16	18	18	20	20	22	22	24	24	26	26
	Qb	1	1	2	2	3	3	4	4	5	5	6	6	7	7	8	8	9	9	10	10	11	11
Weigh	nt (kg) Note 5	4.9	5.3	5.7	6	6.4	6.7	7	7.4	7.7	8	8.4	8.7	9.1	9.4	9.7	10	10.4	10.6	11	11.3	11.7	12.1
	Lead 20							1200							1020	900	780	660	600	540	480	420	360
Maximum speed	Lead 10							600							510	450	390	330	300	270	240	210	180
(mm/sec)	Lead 5							300							255	225	195	165	150	135	120	105	90
(	Speed setting							_							85%	75%	65%	55%	50%	45%	40%	35%	30%
$\overline{}$																							